



Chlor-A-Foam EVO	Product Code
1 gal jug	418087/1
5 gal pail	418087/5
55 gal drum	418087/55

Chlor-A-Foam™ EVO

Product Number: 418087

Key Features

- Phosphate-free formulation
- Formulated using biodegradable detergents
- Superior foaming capabilities
- Excellent for stainless steel, concrete, plastic, fiberglass, and other surfaces
- Formulated using biodegradable detergents
- Brightens and whitens surfaces

Product Description

Chlor-A-Foam™ EVO Hatchery and Equipment Cleaner is a phosphate free, high foaming alkaline cleaner that rapidly removes protein, fat, and carbohydrate soils from surfaces, as well as stubborn yellow stains. Chlor-A-Foam EVO is used for cleaning hatchers, setters, equipment, egg rooms, chick boxes, walls, floors, and refuse areas in poultry hatcheries. In poultry and meat processing plants, it is used for cleaning equipment, shackles, walls, floors, and refuse areas. It is excellent for stainless steel, concrete, plastic, fiberglass, glass, tile, and other surfaces. It can be used through a variety of foam generating equipment as well as in pressure washers.

Active:	Potassium hydroxide and sodium hypochlorite
Use:	Hatcheries, processing facilities, and equipment
Activity:	All purpose, high-foaming detergent
Application:	Foamed or sprayed with pressure washing equipment

Usage Rates

Task	Recommended Dilution	Ratio	oz/gal
Foam cleaning	1.75% - 3% solution	1:64 - 1:32	2 - 4
Foam cleaning for heavy soil loads	4% - 5% solution	1:26 - 1:18	5 - 7
Pressure washing	0.75% solution	1:128	1
Food processing and food contact surfaces	0.75% solution	1:128	1

To learn more, call 800.621.8829 (USA/Canada) or 859.254.1221, or visit NEOGEN.com.

