



Acid-A-Foam EVO	Product Number
1 gal jug	418089/1
5 gal pail	418089/5
55 gal drum	418089/55

Acid-A-Foam™ EVO

Product Number: 418089

Key Features

- Phosphate-free formulation
- Ideal acidic cleaner for a pH rotation program
- Removes mineral scale, detergent residues and other elements left behind after repetitive use of alkaline cleaners
- Formulated using biodegradable detergents
- Superior foaming capabilities
- Compatible with all NEOGEN disinfectants

Product Description

A phosphate free, acidic foaming cleaner, Acid-A-Foam™ EVO is used as an alternative to regular hatchery, equipment or barn cleaner to remove detergent residues, mineral scale and other hard-to-remove elements. A clean surface is required for complete disinfection. Alternating between a good alkaline detergent and a good acid-based detergent maximizes surface cleanliness and, therefore, prepares the surface for the second step of disinfection. Acid-A-Foam EVO removes dirt, grime, protein, and oils as well as minerals and adherent films.

Active:	Glycolic acid
Use:	Acidic foaming cleaner for hatchery or farm use
Activity:	General cleaner, deodorizer, and effectively removes hard water scale and mineral deposits
Application:	Foamed, sprayed with pressure washing equipment, or manual application

Usage Rates

Task	Recommended Dilution	Ratio	oz/gal
General purpose cleaning and foaming	1.75% - 3% solution	1:64 - 1:32	2 - 4
Food processing and food contact surfaces	1.75% - 3% solution	1:64 - 1:32	2 - 4
Barn cleaning	0.25% - 0.5% solution	1:512 - 1:256	0.25 - 0.5

To learn more, call 800.621.8829 (USA/Canada) or 859.254.1221, or visit NEOGEN.com.

