



Acid Tray Wash EVO

Product Number: 418086



Key Features

- Phosphate-free formulation
- Ideal for use through chemical proportioners
- Effectively cleans trays, racks, plastic flats and boxes in automatic washers
- Removes mineral scale, detergent residues, and other build-up from surfaces
- Formulated using biodegradable detergents

Product Description

Acid Tray Wash EVO is an acidified, phosphate-free, non-foaming cleaner for washing trays, plastic chick boxes, egg cases, and filler flats in automatic tray washers. It is also an excellent acidic rinse and equipment descaler.

Acid Tray Wash EVO	Product Code
1 gal jug	418086/1
5 gal pail	418086/5
55 gal drum	418086/55

Active:	Glycolic acid
Use:	Acidic non-foaming cleaner for automated tray washers or general farm use
Activity:	General cleaner, hard water scale, soap scum and mineral deposit remover
Application:	Automated tray washers or pressure washing equipment

Usage Rates

Task	Recommended Dilution	Ratio	oz/gal
For use in automatic washers	0.25% - 0.75% solution	1:512 - 1:128	0.25 - 1
Descaling equipment	0.75% - 4.0% solution	1:128 - 1:26	1 - 5

To learn more, call 800.621.8829 (USA/Canada) or 859.254.1221, or visit NEOGEN.com.

