



BioSentry® AquaPrime® Activator

Product Numbers: 142250, 142550, 142650, 142350, 142450



Key Features

- OMRI Certified
- NSF-approved
- Improves taste and odor of animal drinking water
- Simple 1:2 use ratio of activator to 7.5% sodium chlorite
- Pair with NEOGEN's AquaPrime NeoKlor to generate chlorine dioxide
- Ready to use liquid is green colored for easy indication of presence in injection systems

Product Description

BioSentry AquaPrime Activator is an NSF-approved and OMRI certified special blend of mineral and organic acids specifically formulated to activate stabilized sodium chlorite for the disinfection of animal drinking water in livestock production operations. A simple 1 part activator to 2 parts 7.5% sodium chlorite mix will provide over 90% conversion to free ClO₂.

AquaPrime Activator	Product Number
5 gal pail	142250
15 gal drum	142550
30 gal drum	142650
55 gal drum	142350
275 gal tote	142450

Active:	Acid blend
Use:	Poultry, swine, and dairy operations
Application:	Closed chlorine dioxide generator system

Physical Characteristics
Clear to light green liquid with a pungent, acrid odor. 100% soluble
pH: <1

Usage Rates

Task	Usage Dilution
Drinking water disinfection	1 part BioSentry AquaPrime Activator to 2 parts AquaPrime NeoKlor

Active Ingredients

Sodium chlorite	7.5%
Other Ingredients	92.5%
Total	100.00%

To learn more, call 800.621.8829 (USA/Canada) or 859.254.1221, or visit NEOGEN.com.

