



Dyne-O-Might®

Product Number: 404184



Key Features

- Eliminates Clostridium perfringens which has been shown to cause gangrenous dermatitis
- Ammonia control and dust inhibitor
- User friendly: GRAS active ingredients
- Performs well in high levels of organic soil and hard water
- Provides an acidic pH alternative to add into cleaning rotation

Product Description

Dyne-O-Might® is a disinfectant and ammonia neutralizer. The oxidizing and pH reducing effect of the acids help to permeate and break down cells walls. This provides a proven germicidal ability against pathogens such as E. coli and Salmonella in the presence of 50% organic material. Additionally, Dyne-O-Might is used for ammonia control in poultry facilities. Formulated with feed-grade ingredients, it is safe for use in all areas of the animal agriculture facility including: nurseries, farrowing, breeding and gestation rooms, poultry litter, drinking water and foot baths.

Dyne-O-Might	Product Number
1 gal jug	404184/1
5 gal pail	404184/5
55 gal drum	404184/55
275 gal tote	404184/275

Active:	Iodine
Use:	Poultry farms, cattle barns, ratite facilities, swine facilities, dairy facilities, foot baths, zoos
Activity:	Disinfectant
Application:	Mechanical coarse sprayer, boot baths

Usage Rates

Task	U.S.	Metric
For general disinfection	6.4 oz/1 gal	51.2 mL/L
Ammonia neutralization	1 gal/100 gal of water applied	3.78 mL/378.5 L of water applied
<i>Refer to label for square footage application recommendations</i>		

Active Ingredients

Iodine.....	0.42%
Inert Ingredients.....	99.58%
Total	100.00%



Dyne-O-Might

Physical Properties	
State:	Liquid
Color:	Amber
Odor:	Propionic acid
pH:	0.50 - 1.50
Soluble in water:	Soluble

Bacteria and Fungi	
<i>Escherichia coli</i>	<i>Pasteurella multocida</i>
<i>Pseudomonas aeruginosa</i>	<i>Salmonella typhimurium</i>
<i>Salmonella enterica</i>	<i>Staphylococcus aureus</i>
<i>Salmonella pullorum</i>	<i>Aspergillus glaucus</i>
<i>Clostridium perfringens</i>	<i>Aspergillus fumigatus</i>

Viruses	
Avian Influenza Virus (H3N2)	Infectious bursal disease virus

Please see this product's entire label and follow all use directions and use precautions. Use only for the sites, pests, and application methods described on the product label. It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

To learn more, call 800.621.8829 (USA/Canada) or 859.254.1221, or visit NEOGEN.com.

