



# Farm-Foam EVO

Product Number: 418088



## Key Features

- Phosphate-free and chlorine-free formulation
- Easy application and rinsing
- Formulated using biodegradable detergents
- Superior degreasing capabilities

## Product Description

Farm-Foam EVO is a phosphate free, foaming, alkaline cleaner used for the removal of organic soils, especially fats and grease. Farm-Foam EVO is ideal for the removal of fecal material and soil in swine and poultry premises, hatcheries, and other animal confinement facilities. Farm-Foam EVO removes dirt, grime, protein, and oils, as well as minerals and adherent films.

Farm-Foam EVO	Product Code
1 gal jug	418088/1
5 gal pail	418088/5
55 gal drum	418088/55

<b>Active:</b>	Sodium hydroxide
<b>Use:</b>	Alkaline foaming cleaner
<b>Activity:</b>	General cleaner, deodorizer and wetting agent
<b>Application:</b>	Foaming equipment, pressure washing or manual application

## Usage Rates

Task	Recommended Dilution	Ratio	oz/gal
For general purpose, food processing applications, or farm premise use	0.25% - 0.75% solution	1:512 - 1:128	0.25 - 1
Foaming applications	0.75% - 2.5% solution	1:128 - 1:32	1 - 4

To learn more, call 800.621.8829 (USA/Canada) or 859.254.1221, or visit [NEOGEN.com](http://NEOGEN.com).

