



BioCres™

Product Number: D12204571



BioCres	Product Number
1 gallon (3.79 L) jug	D12204571

Benefits

- Contains cresylic acid and sodium hydroxide
- Broad range of applications
- Penetrates pores, cracks, and crevices to maximize cleaning potential
- Recommended for use on a variety of surfaces

Product Description

Water soluble cresylic cleaner for use in poultry, swine, veal, dairy, cattle, canine, and horse operations. BioCres™ can be used for cleaning broiler houses, brooders, layer houses, livestock barns, farrowing pens, foaling pens, stalls, calf hutches, pig parlors, kennels, poultry crates, animal transport vehicles, and farm equipment. BioCres is recommended for use on surfaces such as concrete, wood, plastic, glazed tile, enameled, and metal surfaces of livestock housing, handling equipment, and transportation equipment.

Usage Directions

Remove all animals, poultry, and feed from premises, trucks, and enclosures. Remove all litter from floors, walls, and surfaces of barns, pens, stalls, chutes, and other facilities occupied or traversed by animals or poultry. Remove gross soil by hosing with water, brushing, vacuuming, or sweeping before using BioCres. Apply solution as a soft coarse spray or with a brush, sponge, or mop. For maximum cleaning effectiveness, allow treatment to remain on the surface for at least 10-20 minutes before flushing with water. Spraying or misting of the product is not recommended unless operator is protected from breathing the spray mist.

Actives:	Cresylic acid and sodium hydroxide
Use:	Alkaline, foaming cleaner for farm premises
Activity:	General hard surface cleaner
Application:	Spray or foam – not recommended as a mist unless a respirator is used

Usage Rates

Task	Usage
Clean premises with BioCres at 0.5% solution	1 gallon in 200 gallons of water 2 ounces per 3 gallons of water 5 mL/L



Physical Properties	
State	Liquid
Color	Dark Brown
Odor	Aromatic
pH, 25° C	12.5
Density	9.6 lbs/gal
Flash Point	104 C
Volatility	23 - 26% (by volume)

Please see entire product label and follow all use directions and use precautions. Use only for the sites and application methods described on the product label. It is a violation of Federal law to use this product or products in a manner inconsistent with its labeling.

To learn more, call 800.621.8829 (USA/Canada) or 859.254.1221, or visit NEOGEN.com.