

Agri-Screen Procedure for Fumonisin

Note: Samples must be diluted before performing test.


Please read kit instructions completely before beginning. Questions? Call 800/234-5333 or 517/372-9200.



1. Add 100 μ L conjugate to each red marked mixing well.



2. Add 100 μ L control and diluted sample to their respective wells. Mix.



3. Transfer 100 μ L to antibody wells. Incubate for 5 minutes. Mix by sliding the wells side to side for the first minute.



4. Dump liquid from antibody wells.



5. Wash wells thoroughly 5 times with deionized water.



6. Tap out water on absorbent paper towel.



7. Add 100 μ L substrate to wells. Incubate for 10 minutes.



8. Add 100 μ L Red Stop to wells.



9. Visually read results.

Product Specifications

Control provided:	5 ppm
Testing time:	12-15 minutes
Antibody cross-reactivity:	Total fumonisins (B ₁ , B ₂ , B ₃)



620 Leshar Place • Lansing, MI 48912
800/234-5333 (USA and Canada only) • 517/372-9200 • fax: 517/372-2006
e-mail: foodsafety@neogen.com • www.neogen.com